



APPLICATIONS:

Airports
Correctional Facilities
Arenas
Public Buildings
Private Buildings
Schools
Special Events
Loss Prevention
Nuclear Facilities
Transportation Terminals
Courthouses
Corporate Security
Historical Landmarks



Visit us online at
www.garrett.com

World Renowned Hand-Held Metal Detector

Proven to accurately detect concealed metallic items, the SuperScanner is the most recognized hand-held metal detector in the world. Used in conjunction with walk-through metal detectors in numerous security screening applications, the Garrett SuperScanner has led the industry for more than 20 years.

FEATURES

- One switch operation—turn it on and begin using it.
- Ultimate sensitivity.
- Does not require adjustments.
- Rugged, high-impact ABS case with reinforced coil compartment.
- Detects medium sized pistol from 9"; large knife from 6"; razor blade and box cutter from 3"; foil-wrapped drugs and tiny jewelry from 1".
- Large 10" scan surface for quick, thorough scanning.
- No tools required to change 9V battery.
- Sharp audible alarm and bright red LED light indicates the detection of metal.
- Momentary push button temporarily eliminates detection of nearby ambient metal such as rebar, metal walls, etc.
- Green LED light indicates ON; Amber LED indicates low battery; Red LED indicates ALARM.



TRAINING

Garrett Metal Detectors is the only manufacturer to offer an advanced training course in metal detection checkpoint screening. Now, you can learn from the industry's leading team of metal detection experts. Call today to enroll in The Garrett Academy.

GARRETT
Academy of Metal Detection

SuperScanner

Hand-Held Metal Detector



GARRETT
METAL DETECTORS

GARRETT: The Global Leader of Security Metal Detectors and Checkpoint Screening

Model # 1165180

SPECIFICATIONS

Operating Temperatures

-35° F (-37° C) to 158° F (70° C)

Humidity

To 95% noncondensing

Audio Frequency

2kHz Warble

Tuning

Automatic

Indicators

Speaker

LED Alert Lights

Green: Power ON

Amber: Battery LOW

Red: ALARM condition

Controls

Power switch (On / Off)

Interference Elimination Momentary Switch

Battery

Single 9 volt battery provides up to 60 hours of normal operation. Optional NiMH rechargeable battery provides up to 20 hours on each 12-hour recharge

Dimensions

Width: 3.25" (8.3 cm)

Thickness: 1.625" (4.13 cm)

Length: 16.5" (42 cm)

Weight: 17.6 oz (500 g)

Warranty

Limited, 24 months parts and labor



ACCESSORIES

A. Rechargeable Battery Kit—Allows recharging without the need to remove the battery. Includes environmentally friendly Cadmium free Ni-MH battery and charger.

110V (Model # 1610200)

220V (Model # 1610800)

B. Earphone

(Model # 1600100)

C. Leather Belt Loop Harness

(Model # 1600800)

D. Belt Holder—Made of durable ballistic weave material and can be worn on a belt or mounted in a car.

(Model # 1611600)

E. Security Products Video—Details features, controls and operation tips on effective scanning techniques. DVD also includes videos on the SuperWand™ Hand-Held Detector, THD™ Tactical Hand-Held Detector and PD 6500™ walk-through metal detector.

DVD (Model# 1678600)



1553100 REV. D • Revised: August 2007 • © 2007 Garrett Electronics, Inc.

REGULATORY INFORMATION

The SuperScanner meets or exceeds all performance specifications of the National Institute of Justice Standard - 0602.02 "Hand-Held Metal Detectors for Use in Concealed Weapon and Contraband Detection."

Meets CE and other international standards for electromagnetic compatibility and safety.

Extensive research has found no information that would indicate Garrett products have adverse effects on pregnancy, medical devices (such as pacemakers) or magnetic recording media. However, directives by physicians and medical device manufacturers regarding metal detectors should be followed.

1881 W. State Street • Garland, Texas 75042 • Tel 972.494.6151 • Fax 972.494.1881 • Email security@garrett.com

www.garrett.com • Safety. Security. Peace of Mind.™